



Installation Checklist

Installation Materials:

- ☐ Flat trowel or drywall taping knife
- ☐ Mixing bucket
- ☐ Modified thinset mortar that meets or exceeds ANSI A118.4 / A118.15 standards

1. Prepare the Substrate and Valve Opening

- ☐ Ensure the substrate and waterproofing system (membrane or shower board) are installed in accordance with the manufacturer's installation guidelines.
- ☐ Verify the mixing valve opening is clean, properly sized, and free of debris.
- ☐ Dry-fit the DMX Mixing Valve® to confirm proper fit and coverage before installation.

2. Install the Mixing Valve

- ☐ Apply modified thinset mortar or approved sealant, around the penetration/opening.
- ☐ Install the DMX Mixing Valve® Seal over the valve body, ensuring full coverage of the opening.
- ☐ Press the seal firmly into place to achieve full contact with the substrate or waterproofing surface.
- ☐ Smooth out the seal using a flat trowel, pressing the fleece into the mortar to ensure full contact and a flush finish.
- ☐ Ensure the seal is fully bonded and watertight around the entire opening.