

DMX PIPE SEAL[®]

Installation Checklist

Installation Materials:

- ☐ Flat trowel or drywall taping knife
- ☐ Mixing bucket
- ☐ Modified thinset mortar that meets or exceeds ANSI A118.4 / A118.15 standards

1. Prepare the Substrate and Pipe Penetration

- ☐ Ensure the substrate and waterproofing system (membrane or shower board) are installed in accordance with the manufacturer's installation guidelines.
- ☐ Dry-fit the DMX Pipe Seal[®] over the pipe to confirm proper fit before installation.

2. Install the Pipe Seal

- ☐ Verify the pipe penetration is clean, properly sized, and free of debris.
- ☐ Apply modified thinset mortar or approved sealant around the penetration/opening.
- ☐ Install the DMX Pipe Seal[®] over the pipe, ensuring a tight fit around the pipe.
- ☐ Press the seal firmly into place to achieve full contact with the substrate or waterproofing surface.
- ☐ Smooth out the seal using a flat trowel, pressing the fleece into the mortar to ensure full contact and a flush finish.
- ☐ Ensure the seal is fully bonded and watertight around the entire penetration.